



This map is for information only and not to scale. Please note, the reference design, including all road/rail interfaces, may change as a result of further investigations, government approvals or during detailed design.

ROAD/RAIL INTERFACES




LEVEL CROSSING EXAMPLE
Level crossings can be passive or active. This illustration shows an active level crossing.



RAIL-OVER-ROAD EXAMPLE



ROAD-OVER-RAIL EXAMPLE



Legend

- Border to Gowrie alignment
- Boundary between Northern and Central Works Programs
- Northern Works Program
- Central Works Program

CENTRAL WORKS PROGRAM

NORTHERN WORKS PROGRAM

Source: Esri, DigitalGlobe, GeoEye, Earthstar Geographics, CNES/Airbus DS, USDA, USGS, AeroGRID, IGN, and the GIS User Community